


# Service Section

## 5.5 Instrument Panel Wiring Diagram



WIRING HARNESS PLUG PIN DESIGNATION

Pin#	Color	Description	Pin#	Color	Description
1	Red	Starter Solenoid (battery)	6	White	Alternator
2	Black	Ground on Solenoid	7	Tan	Oil / Temp Switch
3	White with Red Stripe	Oil Sender	8	Orange	Fuel Solenoid
4	Red with Blue Stripe	Starter Solenoid	9	Purple	Alternator
5	Blue	Temperature Sender			

Manufactured by



**ODB COMPANY**